




- 1 Use a T15 torx bit, remove 4 screws & take off yellow dome.




- 2 Carefully remove decals exposing 3 screws; save decals to reinstall later.



- 3 Remove 3 screws to detach antenna from shroud.



- 4 Lift antenna from shroud to expose main connector & unplug it.



- 5 Reassemble the receiver so the smart cable routes through the square hole in the rear of the shroud.



- 6 Plug into antenna base & plug Deere connector into cable.



- 7 Gently set antenna base on shroud.



- 7 Route cable as shown to avoid pinching.



- 8 Reinstall 3 screws & removed decals. Attach shroud.







9 Install the RV50 Cable into the end of the Smart Cable

10 Go to the Starfire Main settings page & select the GPS Receiver icon in the Top right corner (F).

11 Go to the serial port page & confirm: Baud Rate is 38400, Output rate at 1Hz & GGA box check marked.



12 Continue to the RTK setup page (G).

13 Set the Radio Channel & Network ID both to 1.

14 Confirm RTK fix.

