



Quick Reference Card

AGCO NT01- NovAtel or Trimble Installation & Set-up

Challenger NT01 display name = AccuTerminal Fendt NT01 display name = VarioTerminal Gleaner NT01 display name = Tyton

For:

2017 Gleaner S9* and newer 2017 RoGator C* series and newer 2017 FT 500/700/800/900/1000 2018 TerraGator C* series and newer 2018 Challenger 1000 and newer 2018 Challenger MT700 and newer 2018 Fendt IDEAL combine and newer 2018 CH MT600E wheeled tractor 2018 CH MT700

*Note: Pins 4 (red) & 5 (brown) on AGCO of BN2027 adapter need to be interchanged for RoGator, TerraGator, & Gleaner

Note: Receiver screen may appear differently than the following screenshots depending on receiver type (NovAtel or Trimble 382)

Install the Elevate & AGCO adapter. Route the Elevate cabling to install the elevate on the roof. Use port X5130 behind the radio knockout on RoGator, TerraGator, & Gleaner.



On the Fendt & Challenger series, it is located on the VDO3
to receiver cabling above the drop-down roof



Note: Placement of the elevate modem on the cab roof is vitally important to performance. User must extend the entire length of the cable away from the receiver as shown below. **DO NOT MOUNT THE ELEVATE DIRECTLY ABOVE THE IN ROOF RECEIVER**



3 On-Screen configuration:

Select Auto-Guide >

Auto-Guide(again) >

















Quick Reference Card AGCO NT01- NovAtel or Trimble Installation & Set-up

4 Select:

RTK network as signal type >
External Modem as Modem type >
Choose the correct Baud rate for your corresponding external modem >
Data parity None >
Signal Format RTCM3.1.

