

1

Connect the Beacon to the AGI 4 with the adapter cable and black connector on the back of the receiver



2

Navigate to the Wrench icon, then System, then GPS, then Correction; configure the GPS correction source page to match the screenshot:



3

Return to the Run screen to confirm RTK fix as in the screenshot:

