



### AGCO NT01 Display Setup

Challenger NT01 display name = AccuTerminal

Fendt NT01 display name = VarioTerminal

Gleaner NT01 display name = Tyton

For:

2017 Gleaner S9\* and newer

2017 RoGator C\* series and newer

2017 FT 500/700/800/900/1000

2018 TerraGator C\* series and newer

2018 Challenger 1000 and newer

2018 Challenger MT700 and newer

2018 Fendt IDEAL combine and newer

2018 CH MT600E wheeled tractor

2018 CH MT700

**\*Note: Pins 4 (red) & 5 (brown) on AGCO of  
BN2027 adapter need to be interchanged for  
RoGator, TerraGator, & Gleaner**

Receiver screen may appear differently than the following screenshots depending on receiver type (NovAtel or Trimble 382)

1

Install the RV50 cable. Use port X5130 behind the radio knockout on RoGator, TerraGator, & Gleaner.



2

On the Fendt & Challenger series, it is located on the VDO3 to receiver cabling above the drop-down roof panel.





### 3 On-Screen configuration:

Select Auto-Guide >



Auto-Guide(again) >



System >



Signal



### 4 Select: RTK network as signal type > External Modem as Modem type >

Choose the correct Baud rate for your  
corresponding external modem >  
Data parity None >  
Signal Format RTCM3.1.

