



support@digifarm.com
Part #BN4000-19
Product Store Link

319.531.7574



Quick Reference Card

John Deere SF6000 Installation & Set-up

If your receiver has the radio attached, remove radio before cable installation. If no radio is present, move to step #4.

- Use a Philips screw driver, take out the 2 screws holding the radio in place.
- Pull the radio away from the receiver.
 Unplug the radio cable.
- Place the orange dust cap onto the male end of the plug and push cable into receiver.







- Use the 3 screws included in your Beacon 4.0 kit and attach to backet. Screw bracket on receiver with the 2 screws removed from radio un-installation.
- Plug in the small black male connector into the bottom of the Beacon 4.0
- Place the receiver onto the roof bracket. Unplug the receiver from the roof connection, plug in the male end of the T-cable to the roof and the female end into the receiver cable.







Finished Installation



John Deere Receiver Set-up



Technical Support 319.531.7574 support@digifarm.com

Part #BN4000-19
Product Store Link



Quick Reference Card


John Deere SF6000 Installation & Set-up

7

Pair your Beacon 4.0 with the GR Tech NBV1 NTRIP Client iOS App. Once paired your iPad will ask to download directly from the Apple App Store. See our App QRC for set-up details.




Go to the Starfire Main settings page & select the GPS Receiver icon in the Top right corner (F).




Go to the serial port page & confirm:

Baud Rate is 38400, Output rate at 1Hz


& GGA box check marked.



Continue to the RTK setup page (G).



Set the Radio Channel & Network ID both to 1.



Confirm RTK fix.

